

87-Q_I: Viscosity of Oil


Time $1\frac{1}{2}$ hr.

Apparatus

Tall burette (250ml) or 500ml measuring cylinder; 4 steel ball bearings of different diameters (between 0.2 and 0.65cm); micrometer screw gauge; liquid L; ruler; stopwatch; strong magnet; forceps; thermometer (0–100°C); clamp and stand (if burette is used only); 2 small dishes; note giving values of ρ_1 and ρ_2 ; graph paper.

The aim of this experiment is to determine the viscosity of liquid L. Proceed as follows:

- Set up the apparatus as shown below with burette C nearly filled with liquid L.



- b. Determine and write down the diameters of all the steel ball bearings using the micrometer screw gauge. Then wet all the balls with the liquid L by keeping them in a small dish containing the liquid. (8 marks)
- c. By using the forceps, drop the balls one by one in the liquid. Measure and record the time taken by each ball to fall the distance S between points x and y in the liquid. The point x should be chosen such that the distance from the meniscus of the liquid to x is at least 7cm. The point y should be at least 20cm away from x . Measure and record the distance S with a ruler. The bar magnet may be used to pull out the balls from the liquid L in the burette.

Make a table of results and tabulate the following: Average diameter (d) of each ball in cm, the square of the radius (r^2) of each ball in cm^2 , the average terminal velocity v of each ball in cm s^{-1} . Record the room temperature. (marks: t 8, s 2, r^2 2, v 4)

- d. Plot a graph of r^2 vs. v and draw the best line through the points. Calculate the slope of the graph. (marks 10, 3)
- e. Determine the viscosity η in SI units of liquid L using the relation:

$$\eta = \frac{2g}{9}(\rho_1 - \rho_2)\frac{r^2}{v}$$

where ρ_1 is the density of the steel balls, ρ_2 is the density of liquid L, and g ($= 9.8\text{ms}^{-2}$) is the acceleration due to gravity. (6 marks)

- f. Give the SI units of η and state any sources of errors in your experiment. (marks 2, 5)