Advanced Level Experimental Physics

F6-1: Self Inductance in AC Circuits


Apparatus

300 turn coil; 2 iron C-cores; C-core clip; ammeter (0 - 1 Adc); voltmeter (0 - 5 Vdc); 3 batteries (3V); 2 x 100 Ω resistors; CRO (oscilloscope); AC power supply; 0.5m ruler; connecting leads (5 short); 1 sheet graph paper.


NB: This experiment requires mains electricity.

Procedure

1. To find the resistance r of the coil, connect the following circuit and use the readings of the ammeter and voltmeter to calculate r:




2. To find the inductance *L* of the coil with an iron core, connect the following circuit:




a. Connect the CRO input to V_1 . Adjust the CRO so that V_1 is about 4V, the supply

being switched to AC. Adjust the CRO so that the AC waveform is seen clearly:




Carefully adjust the power supply so that the peak value of V_1 as seen on the screen is 4V peak.

- b. Now connect the CRO to measure V_R peak. Use this, and the value of **R** to calculate the value of *I* peak for the circuit.
- c. Use the CRO to measure V_2 peak.
- d. Repeat a), b), and c), but using V_1 of 3.5, 3, 2.5, 2, 1.5, 1, 0.5, and 0 volt peak each time.
- e. Tabulate the values of V_R peak, V_2 peak, and I peak.
- f. Measure the cross-sectional area of the iron core and the distance *l* around the centre of the pair of cores as shown below:



Theory

The coil with its iron core has an inductance L, and the copper wire of the coil has a resistance r. An equivalent circuit for the coil is:



The impedance of this combination of r and L is given by:

$$Z = \sqrt{r^2 + \omega^2 L^2} \qquad ---- \text{ equation 1}$$
where:
$$Z = \frac{V_2 \text{ rms}}{I \text{ rms}} = \frac{V_2 \text{ peak}}{I \text{ peak}} \qquad ---- \text{ equation 2}$$
and:
$$\omega = 2\pi f$$

It is also possible to calculate *L* using data about the coil and its core:

$$L = \frac{\mu_0 \mu_r N^2 A}{l}$$

$$L = \frac{\mu_0 \mu_r N^2 A}{l}$$
where:
$$\mu_0 = 4\pi \times 10^{-7} \text{Hm}^{-1}$$

$$\mu_r = \text{relative permeability of the iron}$$

$$N = \text{number of coil turns}$$

$$A = \text{core cross-sectional area}$$

$$l = \text{distance around core}$$

Analysis

- 1. Plot a graph of V_2 peak against I peak, and find the gradient.
- 2. Use the gradient and equation 2 to find the value of $\, Z. \,$
- 3. Use equation 1 to find the inductance of the coil, L.
- 4. Use this value of L, together with the other measured values, and equation 3, to find the relative permeability of this type of iron, μ_r .

5. Look up values of μ_r for different types of iron in a reference table and try to deduce the type of iron alloy used in your iron cores.

Questions

- 1. Use the values of R, r, and L above to calculate the current I peak when $V_1 = 8V$ peak and f = 1 kHz.
- 2. Use equation 3 to estimate L if the iron core is removed. Show that in this case $Z \approx r$. Repeat Q1 using L for the coil without an iron core.
- 3. Briefly explain the energy changes in r and L when:
 - a. The current is + and rising
 - b. The current is a maximum +, and constant
 - c. the current is + and falling
- 4. How can an inductor be constructed so that power losses are kept to a minimum (consider both the design of the coil and the core)?
- 5. Why is it desirable to keep power losses to a minimum in an inductor used in the tuning circuit of a radio receiver?
- 6. Prove that:

$$\frac{V_2 \text{ rms}}{I \text{ rms}} = \frac{V_2 \text{ peak}}{I \text{ peak}}$$
 (from equation 2)

Why in the experiment is V peak measured rather than V rms?

- 7. Sketch on the same graph curves of V and I for an inductor (with r = 0) which is connected to an AC power supply.
- 8. Explain carefully why V_1 peak $\neq V_R$ peak $+ V_2$ peak.

© 2015 <u>CC-BY</u> by Bob Drach and Norman Price Based off of book published ???? About