
#### Advanced Level Experimental Physics

## B3-1: The Moment of Inertia of a Cylinder



# Apparatus

2 mounted rails; 2 different cylinders with axles; metre rule; micrometer screw gauge; stack of books; stop watch; piece of chalk; triple beam balance; graph paper

#### Procedure

- 1. Set up the apparatus as shown above with  $\ PR$  less than 4 cm. Measure  $\ s=AB$  and measure  $\ PQ$ . Record  $\ s$  and  $\ PQ$ .
- 2. Measure and record PR. Calculate  $\sin \theta = \frac{PR}{PQ}$ .
- 3. Place a cylinder at A. Record the time, t, for the cylinder, starting from rest, to roll from A to B.
- 4. Determine the linear acceleration,  $\it a$ , of the cylinder using your readings of  $\it s$  and  $\it t$ .
- 5. Increase PR and repeat steps 2, 3, and 4. Increase PR three more times, repeating steps 2, 3, and 4 to obtain five sets of readings.
- 6. Measure the axle diameter and find the axle radius,  $r_a$ . Find the cylinder radius, r. Measure the mass, M, of the cylinder and axle.
- 7. Repeat steps 2 to 6 for the second cylinder.

### Observations

For each cylinder:

$$M$$
=\_\_\_\_kg

$$r_a$$
 =\_\_\_\_m

Tabulate:

PR (m)	PQ (m)	$\sin \theta = \frac{PR}{PQ}$	s (m)	t (s)	a (ms <sup>-2</sup> )

### Theory

The cylinder loses potential energy ( PE) and gains kinetic energy ( KE) as it moves from A to B. Conservation of energy requires:

$$PE lost = KE gained \\ Mgh = Mgs (sin \theta)$$

Ignoring friction this becomes the  $K\!E$  of the cylinder where the total  $K\!E$  is:

$$KE = KE (linear) + KE (rotational)$$

Therefore:

$$Mgs~(\sin heta) = rac{1}{2} M v^2 + rac{1}{2} I \omega^2$$

Substitute  $v^2=2as$  and  $\omega=rac{v}{r_a}$  :

$$a = \left(rac{Mgr_a^2}{Mr_a^2 + I}
ight) (\sin heta) \hspace{1.5cm} ext{(check this yourself!)}$$

## Analysis

- 1. Plot a graph of a against  $\sin\theta$  for each cylinder on the same sheet of graph paper. Find the gradient of each line.
- 2. Given that  $a=(rac{Mgr_a^2}{Mr_a^2+I})\sin heta$  find I for each cylinder.
- 3. From theory  $I=\frac{1}{2}Mr^2$  where r=cylinder radius. Calculate I using this to check your value from 2 above. Give the % error for your value from 2.
- 4. If I = Mk, find the radius of gyration, k, for each cylinder.
- 5. Calculate the torque necessary to steadily accelerate each cylinder from rest to an angular velocity of 30 radians/s in 2s.

© 2015 <u>CC-BY</u> by Bob Drach and Norman Price Based off of book published ???? About